

- Easy Installation
- Good water resistance
- Responsiveness



### Precautions

- Please read the operating instructions of DADISICK before commissioning.
- Connection, installation and configuration must be carried out by trained DADISICK specialists.
- During debugging, the equipment should be protected from moisture and contamination.
- This device does not constitute a safety component according to the corresponding machine safety standards.
- Do not allow moisture or water to enter the internal components of the sensor and the output contacts of the wiring board.
- Protected against use in explosive atmospheres.
- Do not use solvents, paraffin, propylene glycol, gasoline or other chemically active substances to clean the sensor.
- The sensor should be installed away from moisture, water droplets, dust, corrosive and harmful substances, as well as high temperature, discharge and vibration.
- Do not use the sensor in corrosive environments where the atmosphere contains acids, alkalis, and other corrosive substances.
- In the process of operation and maintenance, DADISICK professionals recommend that you abide by the requirements of "User Electrical Equipment Technical Operation Regulations" and "Labor Protection Regulations in Electrical Equipment Operation". Before connecting the sensor, you must ensure that all connections are correct and that the power and signal lines must not be mixed, otherwise the sensor may be damaged or personnel may be injured.
- Sensors that have reached the end of their useful life should be disassembled and DADISICK recommends disposing of them through a facility that recycles ferrous and non-ferrous metals.

### Packaged content

Sensor	1 pcs
Mounting Nut	2 pcs
Manual	1 pcs

### Dimensions




Figure 1 - CSR30-2000 series dimensions




Figure 2 - CSR30-3000 series dimensions

Model range	CSR30	
Working Distance		
Detection distance 100...2000mm	2000	
Detection distance 150...3000mm	3000	
Shell (size, material)		30GK 30GK
output type		I U IU E2/E4 E3/E5 E7/E9 E6/E8 IE4 IE5 UE4 UE5 R4
Analog output: 4...20mA		I
Analog output: 0...10V		U
Dual analog outputs: 4...20mA + 0...10V		IU
switch output: 1 x NPN		E2/E4
switch output: 1 x PNP		E3/E5
Switching output: 2 x NPN		E7/E9
Switching output: 2 x PNP		E6/E8
Dual output: 4-20mA+ 1 x NPN		IE4
Dual output: 4-20mA+ 1 x PNP		IE5
Dual output: 0-10V + 1 x NPN		UE4
Dual output: 0-10V + 1 x PNP		UE5
Digital output: RS-485 (Modbus RTU)		R4

### parameter

Detection Range	100...2000mm	150...3000mm
Blind Spot	82mm	102mm
Signal Frequency	170KHZ	112KHZ
Running Media	Air (velocity ≤16 m/s)	
Resolution	0.17mm	0.17mm
Repeatability	± 0.15%	
Absolute Accuracy	±1mm	
Response time	82ms	102ms
Output type	PNP / NPN / 4...20mA / 0...10V / RS-485	
Switching Hysteresis	2mm	3mm
On-offlevel	10Hz	9Hz
Power-Up Timer	< 500ms	
Operating Voltage	DC 10...30V	
Overpower Protection	200mA	
Load impedance	1~300 Ohm, U > 1 kOhm	
No-load current	≤ 30mA	
Housing type	Cylindrical, thread M30x1.5	
Shell material	Plastic, polyurethane foam	
Protection Class	IP67	
Connection type	M12 x 1.0 connector (5-pin)	
Ambient temperature	-25...+70°C	
Atmospheric pressure	460...918 mm p.s.l.	
Storage Temperature	-40...+85°C	
Weight	62g	62g


### Electrical connection

symbol/connection: (E2/E4,NPN)	connection mode
	1.BN DC 10...30 V
	2.WH NPN
	3.BU GND
	4.BK
	5.GY Teaching Signal
symbol/connection: (E3/E5,PNP)	connection mode
	1.BN DC 10...30 V
	2.WH Unused
	3.BU GND
	4.BK PNP
	5.GY Teaching Signal
Symbols/Connections: (I/U, analog current or analog voltage)	connection mode
	1.BN DC 10...30 V
	2.WH Unused
	3.BU GND
	4.BK Analog voltage U or analog current I
	5.GY Teaching Signal
Symbol/Connection: (IU, analog current + analog voltage)	connection mode
	1.BN DC 10...30 V
	2.WH Analog current 4-20mA
	3.BU GND
	4.BK Analog voltage 0-10V
	5.GY Teaching Signal
Analog voltage 0-10V symbols/connections: (IE5/UE5, analog + switch PNP)	connection mode
	1.BN DC 10...30 V
	2.WH PNP
	3.BU GND
	4.BK Analog current I or analog voltage U
	5.GY Teaching Signal
Symbols/Connections: (IE4/UE4, analog + switch NPN)	connection mode
	1.BN DC 10...30 V
	2.WH NPN
	3.BU GND
	4.BK Analog current or analog voltage + NPN
	5.GY Teaching Signal
Standard symbols/connections: (E7/E9, dual NPN output)	connection mode
	1.BN DC 10...30 V
	2.WH NPNoutput
	4.BK NPNoutput
	3.BU GND
	5.GY Teaching Signal

Symbol/connection: (E6/E8, double PNP output)	connection mode
	1.BN DC 10...30 V
	2.WH PNPoutput
	4.BK PNPoutput
	3.BU GND
	5.GY Teaching Signal

symbols/connections: (RS485 output)	connection mode
	1.BN DC 10...30 V
	2.WH Signal A (RS-485)
	3.BU GND
	4.BK Signal B (RS-485)
	5.GY Unused

### Indicator status



LEDs on the sensor housing indicate the status of the sensor. (DADISICK professionals remind: switch product overload protection green light, red light are on at the same time)

- Off - the sensor is off;
- Green - object detected;
- Red light on - no object detected;
- Green light flashes - the sensing range of the object is set;
- Blinking red light - complete setup for no object sensing range.

### Instructions




Figure3-Ultrasonic sensor operating range




Figure 4 - Detecting non-smooth objects




Figure 5 - Detecting smooth objects

- The sensor is installed at a distance from the object corresponding to "Zone 2" or "Zone 2+3" (see Figure 3), depending on the object and operating conditions (see points 8 and 15).
- The object must not be within a distance of "Zone 1" or "Zone 4" from the sensor corresponding to the "Zone"
- The sensor should be placed in front of the object so that the reflective surface perpendicular to the sensor axis does not deviate more than 3° from the vertical axis (Fig. 5). If the obliquity of the object increases, the reflected ultrasonic pulse may not be able to pick up the reflected sound waves, making the measurement impossible.
- If the surface of the object is uneven (e.g. gravel, gravel), the permissible deviation of the sensor from the vertical is 3° (Fig. 5). During installation, the sensor may deviate more than 3° from the vertical (Figure 4).
- The sensor should be placed in front of the object so that the reflecting surface is perpendicular to the sensor axis, with a permissible deviation of no more than 3° from the vertical axis (Fig. 5).
- If the tilt angle of the object increases, the reflected ultrasonic pulses may not reach the transducer, making measurements impossible. If the surface of the object is uneven (e.g. gravel, gravel), the permissible deviation of the sensor from the vertical is 3° (Fig. 5).
- During installation, the sensor may deviate from vertical by more than 3° (fig. 4).



Make sure the power and sensor are turned off before connecting/disconnecting the sensor connector.

